


Pressure Gauges 2, 5, 7, 10 Bar



Calibration Chart

2 Bar

Bar (x100Kpa)	0	1	2
Resistance	10	99	184

5 Bar

Bar (x100Kpa)	0	0.5	1	1.5	2	2.5	3	3.5	4	4.5	5
Resistance	10	30	48	65	82	99	116	134	151	168	184

10 Bar

Bar (x100Kpa)	0	1	2	3	4	5	6	7	8	9	10
Resistance	10	31	52	71	88	106	124	140	155	170	184