




## Installation Instructions

# NMEA 2000 Navsensor

V1.1 08/2016



# Contents

|                                      |    |
|--------------------------------------|----|
| Preliminary Remarks                  | 4  |
| Safety Instructions for Installation | 4  |
| Safety Instructions for Maintenance  | 6  |
| The VDO Navsensor                    | 7  |
| Components                           | 7  |
| Functions                            | 7  |
| The NMEA Interface                   | 8  |
| Installation of the VDO Navsensor    | 10 |
| Flat mount installation              | 11 |
| Pole mount installation              | 13 |
| Calibration                          | 14 |
| Diagnostic Indication                | 17 |
| Hardware Specification               | 18 |
| Technical Data                       | 19 |
| Accessories                          | 21 |

# **VDO Navsensor**

## **Preliminary Remarks**

In purchasing a sensor from the VDO marine range you have decided on a high value product, which has been manufactured according to acknowledged technical standards. Modern production processes and compliance with currently applicable quality assurance standards guarantee that our products leave the factory in perfect condition.

We thank you for making a good choice, and we are convinced that this instrument will be reliable and of great help to you and keep you safe at sea.

In order to ensure easy and safe handling of your VDO sensor, you should familiarize yourself with all the features and functions.

Please take the time to read these instructions carefully and completely.

## **Safety Instructions for Installation**

This product has been developed, manufactured and tested in accordance with the requirements of EC, UL and FCC directives and the acknowledged state of the art.

Please follow all the instructions given in this handbook exactly.



Please pay attention to all text passages labeled with this symbol. These are very important hints for operating and security of the instruments.



**Before beginning work the native terminal of the battery should be disconnected.**

Use of information provided by the VDO Navsensor does not release you from the responsibility over your ship and demands good seamanship. Always use your nautical experience in interpreting the displayed values.

If you carry out this work yourself, wear suitable working clothes. Do not wear wide fitting clothes. If you have long hair, wear a hair-net. Clothes and hair can get caught in moving and rotating parts.

Wearing of metallic or conductive jewellery, such as necklaces, bracelets, rings etc. is not allowed when working on the electrical installation on board.

Please note that with disconnection of the battery, all volatile electronic memories lose their input values and must be reprogrammed.



**Explosion hazard! Before beginning work on the engine compartment of petrol engines, switch on the ventilator of the engine compartment.**

Ensure that necessary clearance is provided behind the cable opening, at the position where the sensor is to be installed.

When selecting the installation position for the sensor, take care that no stringers are drilled. Be careful also of furniture, floorboards, superstructure boxes, cables etc.

When carrying out installation work with a sealing compound, solvent vapours can be formed. Make sure of adequate ventilation and follow the instructions for use of the sealing compound manufacturer.

For the installation only use VDO or NMEA approved cables.

If you don't use standard cables, the wires used should be adequately insulated or should have sufficient electrical strength, and the contact point should be protected against electrical shock hazard. The electrical conducting components of the connected consuming devices should also be protected against direct contact through suitable measures. Installation of bare metallic wires and contacts is not allowed.

Take account of the wire cross section. A reduction of the wire cross section results in a higher current density. This can cause the wire to heat up and potentially catch fire.

Connect the wires only in accordance to the wiring diagram.

## **Safety Instructions for Maintenance**

The sensor display unit is maintenance-free. Do not use cleaning agents.

Repairs on the sensor should be carried out only by VDO authorized specialists



## The VDO Navsensor

The multifunctional VDO Navsensor is the gem of all sensors. The inertial sensor complements the inbuilt satellite receiver module (GPS) to provide accurate readings of the speed of travel as well as the pitch & roll (up and down) and YAW (sideways) motion of the boat. Compass readings can be displayed electronically thanks to the fluxgate, which also facilitate course corrections in electronic autopilots.

The barometer and air temperature sensors are early indicators of forthcoming weather conditions.

## Components

In the box:

- Navsensor
- Flat mount bracket
- Pole mount bracket
- Installation instruction
- Mounting screws (not magnetic)
- Warning Sticker

## Functions

The sensor provides following information via NMEA 2000:

- GPS-Position
- Date/Time (UTC)
- Speed over Ground

- Course over Ground
- Elevation
- Heading
- Barometric Pressure
- Air Temperature
- Rate of Turn
- Pitch and Roll

## The NMEA Interface

The VDO Navsensor is a NMEA certified sensor. It transmits and receives NMEA 2000 data to an existing NMEA 2000 network

The parameter group numbers (PGN) of the data which the sensor sends are given in the table below. More information about NMEA can be found under [www.nmea.org](http://www.nmea.org)



### Receiving PGNs

| PGN    | Message name                          |
|--------|---------------------------------------|
| 59392  | Acknowledgment ISO                    |
| 60928  | Address Claim ISO                     |
| 126208 | Command Group Function                |
| 59904  | Request ISO                           |
| 60160  | Transport Protocol, Data Transfer ISO |
| 60416  | Transport Protocol ISO                |

## Transmitting PGNs


| <b>PGN</b> | <b>Message name</b>           |
|------------|-------------------------------|
| 59392      | Acknowledgment ISO            |
| 60928      | Address Claim ISO             |
| 65240      | Commanded Address ISO         |
| 126208     | Command Group Function        |
| 126464     | TX/RX PGN List Group Function |
| 126993     | Heartbeat PGN                 |
| 126996     | Product Information           |
| 126998     | Configuration Information     |
| 127250     | Vessel Heading                |
| 127251     | Rate of Turn                  |
| 127257     | Attitude                      |
| 129025     | Position, Rapid Update        |
| 129026     | COG & SOG, Rapid Update       |
| 129029     | GNSS Position Data            |
| 129033     | Local Time Offset             |
| 130311     | Environmental Parameters      |
| 130314     | Actual Pressure               |
| 130316     | Temperature, Extended Range   |
| 127258     | Temperature (Old Version)     |

## Installation of the VDO Navsensor




Before beginning, disconnect the negative terminal on the battery, otherwise you risk a short circuit. If the craft is supplied by auxiliary batteries, you must also disconnect the negative terminals on these batteries! Short circuits can cause fires, battery explosions and damages to other electronic systems. Please note that when you disconnect the battery, all volatile electronic memories lose their input values and must be reprogrammed.

### Where to install



Mount the Navsensor at least 1m away from VHF antennas and clear of radar arrays




Mount the sensor as midship as possible and with clear sky view

Note: If installed on steel hull vessels, install the sensor as high as possible away from the magnetic steel.

## Warning Label


Please place the included warning sticker near the installation location



## Flat mount installation

### Warning

DO NOT attach a Navsensor where it can cause a person to fall down or where a person can accidentally hit it with their foot and cause damage to the device.



### Warning

Always put a grommet in a hole made for cable access.

Use the mounting bracket to give the locations of the four stainless steel non magnetic screws:

1. Put the mounting bracket **(3)** on the vessel where you are to attach it. Make sure that you will not cause damage to other equipment, ropes or electrical cables when you attach the bracket.
2. Use the mounting template to mark the position of the four attachment holes. Examine the location again to make sure that it is a good location, then drill 4 x 3.5 mm holes.

Note: If screws are to attach the bracket to wood, drill 1.5 mm pilot holes and not 3.5 mm clearance holes.


3. Use two screws to temporarily attach the bracket to the vessel.
4. Put a 15 mm dia. drill bit into the centre of the mounting bracket and drill a cable access hole into the vessel. Remove the two attachment screws and bracket. Deburr all holes and clean them fully.
5. Put a 15 x 6 mm grommet on to a NMEA 2000 micro cable (Not supplied). Carefully push the cable through the hole and set the grommet in this hole.
6. Push the NMEA 2000 micro cable through a bracket gasket (if used) and then the bracket. Align the bracket to its attachment holes in the vessel.
7. Use the not magnetic stainless steel screws to attach the bracket to the vessel.

Do not cause damage to the cable or surface of the vessel.

8. Align the keyway in the cable connectors and then push the NMEA cable into the socket in the bottom of the Navsensor **(1)**. Turn the collar to lock the cable
9. Make sure that the arrow on the bottom of the sensor is aligned with the vessel's keel
10. Put the Nav sensor on to the bracket. Carefully push the cable through the grommet in the access hole while you do this.
11. Tighten the set screw **(2)** (3 mm hex key).
12. Get the free end of the NMEA 2000 micro cable and connect it to a T-junction of a existing NMEA 2000 backbone.

Note: Make sure that you set the cable away from sources of Electrical Magnetic interference. Also make sure that the foot of a person cannot touch the cable and cause injury to the person or cause damage to the cable.

## Pole mount installation



### Warning

Always put a grommet in a hole made for cable access.

Attach the Navsensor housing to a pre-installed threaded pole:

1. Turn the mounting collar **(3)** fully on to the pole. Maximum torque to use is 12 Nm. This pole must have an external thread 1-14 UNS-2A.
2. Push the NMEA 2000 micro cable through the mounting collar and pole.

Note: Be careful when you move the cable. Make sure that no sharp edges can cause damage to the cable insulation.

3. Align the keyway in the cable connectors and then push the NMEA cable into the socket in the bottom of the Navsensor **(1)**.

Turn the collar to lock the cable.

4. Carefully push the cable through the mounting pole, put the Navsensor on to the mounting collar and align the arrow on the bottom of the sensor with the vessel's keel

5. Tighten set screw **(2)** (3 mm hex key).

Do not cause damage to the cable or surface of the vessel.

6. Get the free end of the NMEA 2000 micro cable and connect it to a T-junction of a existing NMEA 2000 backbone.

## Calibration


The Navsensor comes along with a built in fluxgate compass, able to calibrate itself to the influence of magnetic components of the vessel. Since this interference may change over time, the calibration should be performed from time to time.

### **The compass calibration routine should be executed:**

- after the installation of the NavSensor
- before and after long voyages
- after installation of new electronic components
- after welding work
- at least once a year (at beginning of the season)

The calibration is performed by turning the boat for two full circles. To get the best accuracy please be aware of the following conditions:


- The circle diameter should have about 4 to 6 times the length of the hull
- The circles should be as round as possible
- The speed of the boat should be around 2-3kn.
- The maneuver should be carried out away from boat traffic, large ships and harbor installations
- The weather conditions should be calm (low wave height and wind speed)



### Please execute following steps:

1. Start turning the boat in a clockwise direction and then press the push button on the Navsensor for 5 seconds (the color turns from green to steady red)
2. Continue turning the boat until the red color of the button goes back to grey (approx. after 1 1/5 circles)
3. Start turning the boat counter clockwise and press the button again for 2 seconds (the color turns back to steady red) any issues please refer to the LED code list below.
4. Continue turning the boat until the steady red color changes.

Setting push button  
with integrated  
LED



**Note:** During this process there is no compass reading present!

5. At the end of the second circle the NavSensor analyses the data of both circles. If the result doesn't differ more than  $2^\circ$  the new compensation values will be used and the compass is calibrated successfully. In this case the color changes to green ( steady or flashing)

If the data differs by more than 3° the new reading will not be used. In this case the color turns to red (flashing). Please repower the sensor and re-do the calibration.

An unsuccessful calibration can be caused by:

- Bad weather conditions (too high waves and/or strong wind)
- Not the right speed or circle distance performed
- Moving magnetic components close to the sensor
- Electronic equipment close to the sensor
- Improper positioning of the sensor

Note: Red flashing can also be caused by a different internal failure of the NavSensor. Please refer to chapter “Diagnostic Indication”


Note: After the first successful installation and calibration general alignment of the Navsensor in respect to the fore and aft line of the boat should be checked. This is done by performing several plottings to different landmarks (please take magnetic variation into account as well). If there is a deviation in the alignment, the sensor should be turned on its bracket accordingly (if so, an additional sensor calibration has to be performed afterwards).

## Diagnostic Indication

| LED color | LED Status    | Comment                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|-----------|---------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Green     | steady lit    | Everything is working ok                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| Green     | 1 Hz flashing | Compass is working ok; GPS has no satellite reception                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| Red       | steady lit    | Compass calibration circle is performed                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| Off       |               | Compass calibration first circle is completed or power fail                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| Red/Green | 1 Hz flashing | Supply voltage too low (below 9V)                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| Red       | 1 Hz flashing | <p>Possible root causes:</p> <p>External failures:</p> <ul style="list-style-type: none"> <li>- Over voltage (above 30V)</li> <li>- NMEA 2000 network problems (e.g. missing terminator)</li> </ul> <p>Internal failures:</p> <ul style="list-style-type: none"> <li>- Memory lost</li> <li>- GPS sensor communication failed</li> <li>- Compass electronic failure</li> <li>- Acceleration or gyro sensor communication failed</li> <li>- Barometer module communication failed</li> </ul> <p>Other failures:</p> <ul style="list-style-type: none"> <li>- Compass calibration failed (not accurate)</li> </ul> |


# Hardware Specification

## Sensor




## Brackets


### Flat Mount:



### Pole Mount:



## Pinout



| Pin | Signal        |
|-----|---------------|
| 1   | Shield        |
| 2   | NET-S (V+)    |
| 3   | NET-C (V-)    |
| 4   | NET-H (CAN H) |
| 5   | NET-L (CAN L) |

## Technical Data

|                                                   |                                                                  |
|---------------------------------------------------|------------------------------------------------------------------|
| <b>Housing Material</b>                           | Mounting/Housing: Plastic (PBT-ASA-GF30FR)<br>Top: Plastic (ASA) |
| <b>Dimensions</b>                                 | WxH: 100 x 108.3 mm                                              |
| <b>In-/Outputs</b>                                | See "In-/Output Table" below                                     |
| <b>Unit weight</b>                                | 250g                                                             |
| <b>Operating temperature</b>                      | -20° / +70°                                                      |
| <b>Storage temperature</b>                        | -30° / +80°                                                      |
| <b>Operating voltage range</b>                    | 8 – 16 VDC                                                       |
| <b>Current consumption</b>                        | ~50mA                                                            |
| <b>GPS channels</b>                               | 66 channels (22 Tracking, 66 Acquisition)                        |
| <b>GPS datum</b>                                  | WGS-84 (default)                                                 |
| <b>GPS-time to first fix</b>                      | Cold (open sky): 33s (typical)<br>Warm (open sky): 1s (typical)  |
| <b>GPS frequency range</b>                        | 1575.42MHz ± 1.023MHz                                            |
| <b>GPS position accuracy</b>                      | Autonomous: 3m (2D RMS)                                          |
| <b>GPS max. altitude</b>                          | < 50,000 m                                                       |
| <b>GPS max. velocity</b>                          | < 515 m/s                                                        |
| <b>Air temperature range</b>                      | -20° / +65°C                                                     |
| <b>Air temperature accuracy</b>                   | +/-1°C                                                           |
| <b>Air temperature adaption time</b>              | 30s                                                              |
| <b>Barometer resolution</b>                       | 1hPa                                                             |
| <b>Yaw resolution</b>                             | 1°/s                                                             |
| <b>Yaw range</b>                                  | +/- 100°/s                                                       |
| <b>Yaw zero error</b>                             | +/- 0.7°/s                                                       |
| <b>Calculated heeling resolution</b>              | 1°                                                               |
| <b>Calculated heeling, pitch &amp; roll-range</b> | + / -50°                                                         |
| <b>Compass resolution</b>                         | 0.5°                                                             |
| <b>Compass accuracy</b>                           | >10uT                                                            |
| <b>Compass field strength</b>                     | min 8 – 80 uT                                                    |
| <b>Compass tilt angle</b>                         | + / - 40°                                                        |
| <b>Compass auto calibration</b>                   | by 2 circles (opposite directions)                               |

|                                      |                                                                  |
|--------------------------------------|------------------------------------------------------------------|
| <b>Nominal Position</b>              | NL 0; According to DIN 16257                                     |
| <b>Mounting/Fixing</b>               | Top or pole mount; Thread: 1-14 UNS-2B                           |
| <b>Protection Class</b>              | IP 65<br>According to IEC 60529:2001;<br>in nominal position     |
| <b>Flammability Housing</b>          | UL-94 V0                                                         |
| <b>EMC</b>                           | DIN-EN 61000-6-2:2006<br>IEC 60945:2002<br>DIN-EN 61000-6-3:2011 |
| <b>Reverse Polarity Protection</b>   | Yes, 1 minute                                                    |
| <b>Short Circuit Protection</b>      | Yes, 1 minute                                                    |
| <b>NMEA manufacture code</b>         | 443                                                              |
| <b>NMEA product code</b>             | 8600                                                             |
| <b>Approval</b>                      | CE, NMEA 2000 V2.0                                               |
| <b>VDO product number (packed)</b>   | A2C59501981                                                      |
| <b>VDO product number (unpacked)</b> | A2C96792000                                                      |

# Accessories

| Part Number | Item specifics                                  |
|-------------|-------------------------------------------------|
| A2C38293800 | Mount Navsensor Flat                            |
| A2C97838800 | Mount Navsensor threaded                        |
| A2C96243700 | NMEA 2000 Cable 0.5m                            |
| A2C96243800 | NMEA 2000 Cable 2m                              |
| A2C96244000 | NMEA 2000 Cable 6m                              |
| A2C96244200 | NMEA 2000 Cable 10m                             |
| A2C38804100 | NMEA 2000 Cable 30m                             |
| A2C39308500 | NMEA 2000 Infield Installation Connector Female |
| A2C39310500 | NMEA 2000 Infield Installation Connector Male   |
| A2C39312700 | T Splitter NMEA 2000                            |
| A2C39310600 | NMEA 2000 Terminator Female                     |
| A2C39311000 | NMEA 2000 Terminator Male                       |
| A2C39312500 | NMEA 2000 Inline Terminator                     |
| A2C39312900 | NMEA 2000 Power cable                           |

Continental Automotive Switzerland AG  
Industriestrasse 18  
9464 Rüthi  
Switzerland

[www.marine.vdo.com](http://www.marine.vdo.com)  
VDO – A Trademark of the Continental Corporation

The information provided in this brochure contains only general descriptions or performance characteristics, which do not always apply as described in case of actual use or which may change as a result of further development of the products. This information is merely a technical description of the product. It is not meant or intended to be a special guarantee for a particular quality or particular durability. An obligation to provide the respective characteristics shall only exist if expressly agreed in the terms of contract. We reserve the right to make changes in availability as well as technical changes without prior notice.

A2C99834500 | Continental Automotive Switzerland AG | English © 2016